PLEASE FOLLOW INSTRUCTIONS FOR EASE OF ASSEMBLY

Section 1 Partition Assembly


Section 2 Partition Assembly




1) Start on Flat Surface @ **BEGIN HERE--SECTION 1 --**WHITE SIDE UP



2) Fold First Panel UP--Panel Labeled "BOTTOM" is Held Down.



3) Fold Panel with Instruction #3 UP. Insert TAB A Into SLOT A and TAB B Into SLOT B.



4) With Panel Labeled "TOP" Up Fold Panel with Instruction #4 DOWN. Locking bottom is not necessary at this time.




5) Fold Panel with Instruction #5 UP--Panel Labeled "BOTTOM" is Held Down. Insert TAB C Into SLOT C and TAB D Into SLOT D.



6) With Panel Labeled "TOP" up Fold Panel with Instruction #6 DOWN.




Flip Over **BROWN SIDE UP**--Insert remaining 4 UNMARKED TABS into adjacent SLOTS --Set Aside for Later Assembly-



13. Flip Both SECTIONS WHITE SIDE UP



Join Sections by Inserting Tabs I,J,K & L Into Corresponding Slots I,J,K&L.




FINSHED TRUSS ASSEMBLY Set Aside for Later Insertion in Outer Box.

Construct Box & Insert Truss


Join Partitions -- Sections 1 & 2




a) Unfold--Unfold and Expand Outer Box




b) Construct Bottom.--Fold Single Panel Flush with **Bottom**



c) Fold Panel with 2 Tabs Over Bottom. Insert End Tabs in Slots.




d) Construct Top--Fold 3 Single Panels to Inside **Against Box Sides**



e) Insert Truss Partition into Box As Shown--WHITE SIDE TOWARD PRINTED TOP. (Tabs Inside Box "Lock" in

Place When Partition Inserted)



ADVANCED RGANIZING YSTEMS, INC.

TrussFile--Assembled

(2 TrussFile25's Shown)

Instructions TrussFile001.p65--31Oct2005

PARTS LIST per TrussFile

1 ea. -- SECTION 1 Partition

1 ea. -- SECTION 2 Partition

1 ea. -- Outer Box


AssemblyInstructions The "TrussFile"



7) Start on Flat Surface @ BEGIN HERE--SECTION 2 --WHITE SIDE UP




8) Fold First Panel UP--Panel Labeled "BOTTOM" is Held Down.




9) Fold Panel with Instruction #9 UP. Insert TAB E Into SLOT E and TAB F Into SLOT F.



10) With Panel Labeled "TOP" Up Fold Panel with Instruction #10 DOWN. Locking bottom is not necessary at this time.



11) Fold Panel with Instruction #11 UP--Panel Labeled "BOTTOM" is Held Down. Insert TAB G Into SLOT G and TAB H Into SLOT H.



, 12) With Panel Labeled "TOP" up Fold Panel with Instruction #12 DOWN.



Flip Over BROWN SIDE UP--Insert remaining 4 UNMARKED TABS into adjacent SLOTS --See Step C. to Join Sections--